## Multifuse® Product Selection Worksheet

To select the correct Multifuse® resettable fuse, complete the information below, and refer to the relevant Multifuse product family page.

Determine the <b>NORMAL</b> operating current (I <sub>hold</sub> ):	Amps
Determine the <i>MAXIMUM</i> circuit voltage (V <sub>max</sub> ):	Volts
Determine the <b>MAXIMUM</b> fault current (I <sub>max</sub> ):	Amps
Determine the <b>OPERATING TEMPERATURE</b> range	min °C
	max °C
Which form factor is the most suitable for the application	:
Radial Leaded Through-Hole	
MF-R010 through MF-R090	
MF-RX110 through MF-RX375	
	lhold of 1.1 Amps - 11.0 Amps and (V <sub>max</sub> ) of 30.0 volts
Surface Mount	
MF-SM030 through MF-SM260	lhold of 300 mAmps - 2.6 Amps
	l <sub>hold</sub> of 0.05 Amps - 1.10 Amps
Telecom Products	
MF-R/250lhold of 0.12 - 0.	18 Amps and (V <sub>max</sub> ) of 60.0 volts with surge capability of 250 volts
	hold of 0.13 Amps with surge capability of 250 volts
Axial Leaded Battery Strap	
MF-S120 through MF-S420	I <sub>hold</sub> of 1.2 Amps - 4.2 Amps
MF-LS070 through MF-LS340	lhold of 0.7 Amps - 3.4 Amps
MF-LR190 through MF-LR730	lhold of 1.9 Amps - 7.3 Amps
MF-VS170 through MF-VS210	lhold of 1.70 Amps - 2.10 Amps
Battery Cap	
MF-AAA170 and MF-AAA210	lhold of 1.7 Amps - 2.1 Amps
Disk)	
MF-D	Consult factory

- 6. Check that the maximum ratings for V<sub>max</sub> and I<sub>max</sub> of the product family chosen is higher than the maximum circuit voltage and fault current in the application.
- 7. Using the Thermal Derating Chart on the data sheets, select the Multifuse device at the maximum operating temperature with an I<sub>hold</sub> greater than or equal to the normal operating current.
- 8. Order samples and test in the application. Lab Design Kits for most Multifuse\* product lines are available. Contact your nearest Bourns sales office for more information.